



Getting Started Guide

BlackBerry Tour 9630 Smartphone

 **BlackBerry Tour™**



MAT-24349-001 Rev. 002 | PRINTSPEC-059
SWD-618651-0723044238-001 | RCF7xCW

Contents

Welcome to BlackBerry!	3
Set up your device	5
Insert the battery.....	5
Charge the battery.....	6
Complete the setup wizard.....	8
Learn the basics	11
Move around the screen	12
Applications.....	13
Typing basics.....	14
Home screen status indicators.....	15
Bluetooth indicators.....	16
Message list status indicators.....	16
Phone status indicators.....	17
Calendar status indicators.....	17
Camera status indicators.....	17
Wireless coverage indicators.....	18
Start using your device	21
Make a call.....	21
Send an email message.....	21

Send an SMS text message.....	22
Take a picture	22
Record a video.....	23
Visit a web page.....	24
Schedule an appointment.....	24
Pair with a Bluetooth enabled device.....	25
About using your device with a computer.....	25
About switching devices.....	27
Synchronize data between your device and your computer	28
Insert a media card.....	28
About connecting to a GSM or UMTS network.....	29
Insert the SIM card and battery	30
Find more information.....	32
Carrying your device.....	33
Troubleshooting.....	35
I cannot connect to a wireless network.....	35
I cannot associate my device with an email address	35
I cannot make or receive calls.....	35
Legal notice.....	37

Welcome to BlackBerry!

Get ready to experience the freedom and connectivity of your all-in-one mobile solution. Setting up your BlackBerry® Tour™ smartphone is easy. Simply charge the battery and complete the setup wizard. After you complete the setup wizard, take some time to explore the features on your device. This guide provides tips and instructions to help you learn the basics quickly.

Set up your device

Insert the battery


1. Hold up the release button for the battery cover and lift off the battery cover.
2. Insert the battery so that the metal contacts on the battery align with the metal contacts on your BlackBerry® device.
3. Slide the metal notches at the top of the battery cover into the slots at the top of the device.
4. Push down the battery cover so that it clicks into place.

If the battery is charged, the device turns on. If the device does not turn on, charge the battery.


Remove the battery cover



Insert the battery



Replace the battery cover




Charge the battery


1. Connect the small end of the travel charger cable to the micro-USB port on the side of your BlackBerry® device.
2. If necessary, perform one of the following actions:

- Insert the plug blade attachment into the power adapter.
 - Fold down the plug blades on the power adapter.
3. Plug the power adapter into a power outlet.
 4. Charge the battery to full power.

Connect the travel charger cable to your device



Insert the plug blade attachment or fold down the plug blades (if necessary)



You can use the micro-USB cable that came with your device to connect your device to your computer for charging. For more information, see the "About using your device with a computer" topic.

Battery power level indicators



full battery power



battery charging



low battery power

Complete the setup wizard

The setup wizard is designed to help you learn about typing, change options to personalize your BlackBerry® device, and set up one or more email addresses.

1. On the Welcome screen, read the setup wizard introduction.
2. Click **Continue**.
3. Complete the instructions on the screen.

Note: If the Welcome screen does not appear automatically, on the Home screen, press the  key. In the **Setup** folder, click **Setup Wizard**.

About email setup options

If you have not already set up an email address, you can use one of following options to set up email. Depending on your wireless service provider, the available options might vary.

- **BlackBerry Internet Service option:** Use this email setup option to create a new email address for your device or to associate your device with one or more (up to ten) existing email addresses. This option is most common for individual users. You can set up email using this option by selecting the **I want to create or add an email address** option in the setup wizard on your device.
- **BlackBerry Enterprise Server option:** Use this email setup option to associate your device with a Microsoft® Outlook® work email account, IBM® Lotus Notes® work email account, or Novell® GroupWise® work email account and to take advantage of advanced capabilities for wireless data synchronization. If your administrator has provided you with an activation password, you can set up email using this option by selecting the **I want to use a work email account with a BlackBerry Enterprise Server** option in the setup wizard on your device. If you do not have an activation password, contact your administrator.
- **BlackBerry Desktop Redirector option:** Use this email setup option to associate your device with a Microsoft Outlook (Workgroup Installation) email account. You can set up email using this option by installing the BlackBerry® Desktop Software and selecting the BlackBerry Desktop Redirector option. If you use this email setup option, you must keep your computer turned on to receive email messages.

Add or create an email address using the setup wizard




1. In the setup wizard, on the email setup screen, select the **I want to create or add an email address** option. Click **Next**.
2. Click **Next**.
3. If necessary, click **Update Now**.

4. If necessary, click **Create New Account**.
5. To accept the terms of the license agreement, select the **Yes** option. Click **I Agree**.
6. If necessary, type a login user name and password of your choice. Click **Next**. Record your user name and password in a safe place.
7. Complete the instructions on the screen.

Learn the basics



Move around the screen


- To open the application list from the Home screen, press the  key.
- To move the cursor in any direction and highlight items, roll the trackball.
- To select an item or follow a link, click the trackball.
- To change the value in a field, click a field. Click a value.
- To move back a screen, press the  key.
- To return to the Home screen, press the  key.

Home screen



Application list





Applications

Take some time to explore the applications that are available on your BlackBerry® device. Here are a few applications to get you started.

Depending on your BlackBerry device, the camera or video camera feature might not be supported.



Click **Setup Wizard** in the **Setup** folder to learn about typing, change options to personalize your device, and set up your email address. The setup wizard also provides links to information about common tasks.



Click **Email Settings** in the **Setup** folder to set up one or more email addresses or change BlackBerry® Internet Service email options.



Click **Browser** to visit web pages or view the browser bookmark list.



Click **Camera** to take a picture.



Click **Video Camera** in the **Applications** folder to record a video.



Click **Media** to view saved songs, ring tones, videos, or pictures.



Click **Messages** to view a list of your messages.



Click **Options** to view the main list of device options. You can also access additional options from the menu in each application.



Click **Contacts** to view your contact list or add a new contact.



Click **Help** to view the user guide for your device.

Typing basics

Typing indicators

When you type, typing indicators appear at the top-right corner of the screen.



CAP lock (capital letter lock)












Alt mode











NUM lock (number lock)

Typing tips

- To capitalize a letter, hold the letter key until the capitalized letter appears or press the  key and the letter key.
- To type the alternate character on a key, press the  key and the character key. For example, to type a question mark (?), press the  key and .
- To type a symbol, press the  key. Type the letter that appears below the symbol.
- To type an accented or special character, hold the letter key and roll the trackball to the left or right. Release the letter key when the accented or special character appears. For example, to type ü, hold  and roll the trackball to the left until ü appears.
- To turn on NUM lock, press the  key and the **Left Shift**  key. To turn off NUM lock, press the  key.

Home screen status indicators

	alarm set		missed call count
	unopened message count		sending data
	calendar reminder count		receiving data
	voice mail message		roaming



new notification

Bluetooth indicators



Bluetooth® technology on



Bluetooth technology connected

Message list status indicators



unopened message



MMS message



opened message



sent message



message with an attachment



message is sending



message is high priority



message not sent



SMS text message



draft message



filed message

Phone status indicators



missed call



received call



placed call

Calendar status indicators



reminder set



meeting



recurring appointment or meeting



exception to recurring appointment or meeting



calendar entry with notes

Camera status indicators



flash is turned on



automatic flash mode



flash is turned off



slow shutter speed

Wireless coverage indicators

Indicators on the Home screen display the wireless coverage level for the area in which you are using your BlackBerry® device.

3G 

You can use the phone, send and receive email messages, PIN messages, MMS messages and SMS text messages. You can use the phone and send and receive email messages or use the browser simultaneously.

1XE**V**

You can use the phone, send and receive email messages, PIN messages, MMS messages, SMS text messages, and use the browser with a high-speed data connection.

EDGE

1X

You can use the phone, send and receive email messages, PIN messages, MMS messages, SMS text messages, and use the browser.

GPRS

1X

You can use the phone and send and receive SMS text messages.

D

3G

edge

3g

GSM

gprs

Y SOS

You can only make emergency calls.

Y OFF


Your connection to the wireless network is turned off.


Y X

You are not in a wireless coverage area.


Start using your device

Make a call

1. From the Home screen or in the phone application, perform one of the following actions:
 - Type a phone number.
 - Type part of a contact name. Highlight a contact or phone number.
2. Press the  key.

To end the call, press the  key.



Send an email message

1. On the Home screen, click the **Messages** icon.
2. Press the  key.
3. Click **Compose Email**.
4. In the **To** field, perform one of the following actions:
 - Type an email address.
 - Type a contact name.
 - Type part of a contact name. Click a contact.
5. Type a message.

6. Press the  key.
7. Click **Send**.

Send an SMS text message

You can send an SMS text message to up to ten recipients.

1. On the Home screen, click the **Messages** icon.
2. Press the  key.
3. Click **Compose SMS**.
4. In the **To** field, perform one of the following actions:
 - Type an SMS phone number (include the country code and area code).
 - Type a contact name.
 - Type part of a contact name. Click a contact.
 - If your device is connected to a CDMA network, you can type an email address.
5. Type a message.
6. Press the  key.
7. Click **Send**.

Take a picture

Depending on your BlackBerry® device, the camera or video camera feature might not be supported.

1. On the Home screen, click the **Camera** icon.
2. Perform any of the following actions:
 - To zoom in to or out from a subject, roll the trackball up or down.
 - To lock the focus on a subject by pressing the **Right Convenience** key halfway. Depending on your device model, this feature might not be supported.
3. To take a picture, click the trackball.

Note: The approximate number of pictures that you can save to the BlackBerry® device memory or the media card appears in the lower-left corner of the screen. If you save pictures to the device memory, you might be able to insert a media card into your device to save more pictures.

Record a video


To perform this task, you might need to have a media card inserted in your BlackBerry® device.

1. On the Home screen, click the **Camera** icon.
2. Press the **Menu** key.
3. Click **Video Camera**.
4. Click the trackball.
5. To pause recording, click the trackball again.



Note: The approximate amount of memory available for saving videos appears on the lower part of the screen.

Visit a web page

Depending on your wireless service provider, multiple browsers might appear on your BlackBerry® device. For more information about the charges associated with using each browser, contact your wireless service provider.

1. On the Home screen, click the **Browser** icon.
2. Perform one of the following actions:
 - If a web address field appears on the screen, type a web address.
 - If a web address field does not appear on the screen, press the  key. Click **Go To**. Type a web address.
3. Press the **Enter** key.

Schedule an appointment

1. On the Home screen, click the **Calendar** icon.
2. Press the  key.
3. Click **New**.
4. Type the appointment information.
5. If the appointment recurs, change the **Recurrence** field.
6. Press the  key.
7. Click **Save**.

Pair with a Bluetooth enabled device

Some Bluetooth® enabled devices have a passkey that you must type before you can pair with them.

1. In the Bluetooth setup application, click **Search** or **Listen**.
2. If necessary, click a Bluetooth enabled device.
3. If necessary, type the passkey for the Bluetooth enabled device on your BlackBerry® device.
4. If necessary, type the passkey for the Bluetooth enabled device on the Bluetooth enabled device.

About using your device with a computer

You can install the BlackBerry® Desktop Software on your computer and connect your BlackBerry device to your computer to perform any of the following actions:

- Charge your device.
- Synchronize organizer data such as contacts, calendar entries, tasks, and memos between your device and your computer.
- Back up and restore device data.
- Transfer files between your device and your computer.
- Add applications to your device.

- Set up and manage email message forwarding or wireless calendar synchronization if your administrator has advised you to do so.
- Set up and manage email message forwarding using the BlackBerry Desktop Redirector to forward email messages from a Microsoft® Outlook® (Workgroup installation) email account that resides on a Microsoft Exchange Server version 5.5 or later.

For more information about synchronizing data, backing up or restoring data, adding applications, or other functions, see the *BlackBerry Desktop Software Online Help*.

System requirements: BlackBerry Desktop Software

- Intel® compatible 486 or higher computer that is compliant with USB 1.1 or later
- Windows® XP or later
- BlackBerry® User Tools CD

Install the BlackBerry Desktop Software

1. Verify that your BlackBerry® device is not connected to your computer.
2. Insert the *BlackBerry® User Tools CD* into the CD drive on your computer.
3. Click **BlackBerry Desktop Software**.
4. Complete the instructions on the screen until the Setup Type screen appears.
5. On the Setup Type screen, perform one of the following actions:
 - If you do not want to use the BlackBerry® Desktop Software to synchronize certificates between your device and your computer, select the **Typical** option. Click **Next**.

- If you want to use the BlackBerry Desktop Software to synchronize certificates between your device and your computer, select the **Custom** option. Click **Next**. In the **Certificate Synchronization** drop-down list, click **This feature, and all subfeatures, will be installed on local hard drive**.
6. Complete the instructions on the screen.
 7. When the installation is complete, connect the smaller end of the USB cable to the USB port on the side of your device.
 8. Connect the larger end of the USB cable to the USB port on your computer.
- If the BlackBerry® Desktop Manager does not open automatically, on the taskbar, click **Start > Programs > BlackBerry > Desktop Manager**.

About switching devices

You can import data from your current BlackBerry® device, Palm® device, or Windows Mobile® powered device to your new BlackBerry device using the switch device wizard tool of the BlackBerry® Desktop Manager. For more information about switching devices, see the *BlackBerry Desktop Software Online Help*.

Switch devices

To perform this task you must install the most recent version of the BlackBerry® Desktop Software.

1. Connect your current device to your computer.
2. Open the BlackBerry® Desktop Manager.

3. Click **Device Switch Wizard**.
4. Click **Start**.
5. Complete the instructions on the screen.

Note: Changes that you made to sound profiles on your current BlackBerry device are not imported to your new device.

If you are switching from a BlackBerry device that is associated with the BlackBerry® Internet Service, on your new BlackBerry device, in the setup wizard, open the email setup screen. Update your device PIN.

Synchronize data between your device and your computer


1. Connect your BlackBerry® device to your computer.
2. Open the BlackBerry® Desktop Manager.
3. Click **Synchronize**.
4. Select the check box beside one or more actions.
5. Click **Synchronize**.

Insert a media card

Use a microSD media card to extend the memory available on your BlackBerry® device for storing media files such as songs, ring tones, videos, or pictures. The media card might be sold separately from your device.

1. Hold up the release button for the battery cover and lift off the battery cover.
 2. Hold the media card so that the metal contacts on the media card face down and point toward the right side of your device.
 3. Slide the media card into the media card slot until it stops.
- To remove the media card, slide the media card out of the slot.

Insert the media card



About connecting to a GSM or UMTS network

In global roaming mode, your BlackBerry® device is designed to connect to an appropriate CDMA, GSM®, or UMTS network automatically when you travel. Your wireless service provider must provide you with a SIM card that is set up for global roaming services before you can connect to a GSM or UMTS network. When you insert the SIM card, your device is designed to prompt you to switch to global roaming mode. When you remove the SIM card, your device scans for CDMA networks only.

For more information about global roaming and roaming fees, contact your wireless service provider.

Insert the SIM card and battery

Your SIM card is a small rectangular plastic card that stores important information about your wireless service. Your SIM card might already be inserted in your BlackBerry® device.


1. Hold up the release button for the battery cover and lift off the battery cover.
2. If the battery is inserted, remove the battery.
3. If your SIM card is already inserted, proceed to step 8.
4. Remove the SIM card from any packaging.
5. Hold the SIM card so that the metal contacts on the SIM card face down and the cutoff corner of the SIM card points toward the top-left corner of your device.
6. Slide the SIM card into the SIM card holder until it stops.
7. Insert the battery so that the metal contacts on the battery align with the metal contacts on your device.
8. Slide the metal notches at the top of the battery cover into the slots at the top of the device.
9. Push down the battery cover so that it clicks into place.

If the battery is charged, the device turns on. If the device does not turn on, charge the battery.


Remove the battery cover




Insert the SIM card



Insert the battery



Replace the battery cover



Find more information

- To view the user guide for your BlackBerry® device, click **Help** in the application list or in an application menu.
- To view the BlackBerry® 101 tutorial, user guide, safety and product information booklet, or software license agreement and warranty for your device, insert the *BlackBerry® User Tools CD* that came with your device into the CD drive on your computer.
- To find information about your wireless network or your wireless service plan, visit your wireless service provider web site.
- To find software, games, and accessories for your device, visit www.discoverblackberry.com.
- To buy accessories for your device, contact your wireless service provider or visit www.shopblackberry.com.

Carrying your device

Your BlackBerry® device might not come with a holster (body-worn carrying solution equipped with an integrated belt clip). If you wear the device on your body, always put the device in a holster with an integrated belt clip supplied or approved by Research In Motion. Carrying solutions, including RIM approved carrying solutions and carrying solutions not approved by RIM, that do not come equipped with an integrated belt clip should not be worn or carried on the body. For more information about carrying your device, including separation distances when wearing your device, see the *Safety and Product Information* booklet located on the *BlackBerry® User Tools* CD that came with your device.

To purchase RIM approved holsters equipped with an integrated belt clip or other accessories for your device, contact your wireless service provider or visit www.shopblackberry.com.

Troubleshooting

I cannot connect to a wireless network

Depending on your wireless network, some features might not be supported.

Try performing the following actions:

- Verify that your SIM card is inserted in your BlackBerry® device correctly.
- Verify that you have turned on the connection to the wireless network.

I cannot associate my device with an email address

Try performing the following actions:

- On the email setup screen, verify that you have typed all the email address information correctly.
- Verify that the email address is associated with a supported email account (for example, a POP3 email account or an IMAP email account). For more information about supported email accounts, contact your wireless service provider.

I cannot make or receive calls

Try performing the following actions:

- Verify that your BlackBerry® device is connected to the wireless network.

- Verify that your wireless service plan includes phone or voice services.
- If you cannot make calls and fixed dialing is turned on, verify that the phone number for your contact appears in your fixed dialing list or turn off fixed dialing.
- If you have traveled to another country and you have not changed your smart-dialing options, dial the full phone number, including the country code and area code, for your contact.
- If you are not receiving calls, verify that call blocking and call forwarding are turned off.
- Your device or your SIM card might support more than one phone number, even if you only have one phone number. Verify that your phone number is set as your active phone number.
- If you have more than one phone number associated with your device, verify that the phone number that you want to make calls from and receive calls to is set as your active phone number.

Legal notice

©2009 Research In Motion Limited. All rights reserved. BlackBerry®, RIM®, Research In Motion®, SureType®, SurePress™ and related trademarks, names, and logos are the property of Research In Motion Limited and are registered and/or used in the U.S. and countries around the world.

Bluetooth is a trademark of Bluetooth SIG. GSM is a trademark of the GSM MOU Association. IBM, Domino, Lotus, and Lotus Notes are trademarks of International Business Machines Corporation. Intel is a trademark of Intel Corporation. Microsoft, Outlook, and Windows are trademarks of Microsoft Corporation. Novell and GroupWise are trademarks of Novell, Inc. Roxio is a trademark of Sonic Solutions. All other trademarks are the property of their respective owners.

Portions of the BlackBerry® Device Software are copyright © 2007-2008 The FreeType Project (www.freetype.org). All rights reserved.

The BlackBerry smartphone and other devices and/or associated software are protected by copyright, international treaties, and various patents, including one or more of the following U.S. patents: 6,278,442; 6,271,605; 6,219,694; 6,075,470; 6,073,318; D445,428; D433,460; D416,256. Other patents are registered or pending in the U.S. and in various countries around the world. Visit www.rim.com/patents for a list of RIM (as hereinafter defined) patents.

This documentation including all documentation incorporated by reference herein such as documentation provided or made available at www.blackberry.com/go/docs is provided or made accessible "AS IS" and "AS AVAILABLE" and without condition, endorsement, guarantee, representation, or warranty of any kind by Research In Motion Limited and its affiliated companies ("RIM") and RIM assumes no responsibility for any typographical, technical, or other inaccuracies, errors, or omissions in this documentation. In order to protect RIM proprietary and confidential information and/or trade secrets, this documentation may describe some aspects of RIM technology in generalized terms. RIM reserves the right to periodically change information that is contained in this documentation; however, RIM makes no commitment to provide any such changes, updates, enhancements, or other additions to this documentation to you in a timely manner or at all.

This documentation might contain references to third-party sources of information, hardware or software, products or services including components and content such as content protected by copyright and/or third-party web sites (collectively the "Third Party Products and Services"). RIM does not control, and is not responsible for, any Third Party Products and Services including, without limitation the content, accuracy, copyright compliance, compatibility,

performance, trustworthiness, legality, decency, links, or any other aspect of Third Party Products and Services. The inclusion of a reference to Third Party Products and Services in this documentation does not imply endorsement by RIM of the Third Party Products and Services or the third party in any way.

EXCEPT TO THE EXTENT SPECIFICALLY PROHIBITED BY APPLICABLE LAW IN YOUR JURISDICTION, ALL CONDITIONS, ENDORSEMENTS, GUARANTEES, REPRESENTATIONS, OR WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY CONDITIONS, ENDORSEMENTS, GUARANTEES, REPRESENTATIONS OR WARRANTIES OF DURABILITY, FITNESS FOR A PARTICULAR PURPOSE OR USE, MERCHANTABILITY, MERCHANTABLE QUALITY, NON-INFRINGEMENT, SATISFACTORY QUALITY, OR TITLE, OR ARISING FROM A STATUTE OR CUSTOM OR A COURSE OF DEALING OR USAGE OF TRADE, OR RELATED TO THE DOCUMENTATION OR ITS USE, OR PERFORMANCE OR NON-PERFORMANCE OF ANY SOFTWARE, HARDWARE, SERVICE, OR ANY THIRD PARTY PRODUCTS AND SERVICES REFERENCED HEREIN, ARE HEREBY EXCLUDED. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY BY STATE OR PROVINCE. SOME JURISDICTIONS MAY NOT ALLOW THE EXCLUSION OR LIMITATION OF IMPLIED WARRANTIES AND CONDITIONS. TO THE EXTENT PERMITTED BY LAW, ANY IMPLIED WARRANTIES OR CONDITIONS RELATING TO THE DOCUMENTATION TO THE EXTENT THEY CANNOT BE EXCLUDED AS SET OUT ABOVE, BUT CAN BE LIMITED, ARE HEREBY LIMITED TO NINETY (90) DAYS FROM THE DATE YOU FIRST ACQUIRED THE DOCUMENTATION OR THE ITEM THAT IS THE SUBJECT OF THE CLAIM.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW IN YOUR JURISDICTION, IN NO EVENT SHALL RIM BE LIABLE FOR ANY TYPE OF DAMAGES RELATED TO THIS DOCUMENTATION OR ITS USE, OR PERFORMANCE OR NON-PERFORMANCE OF ANY SOFTWARE, HARDWARE, SERVICE, OR ANY THIRD PARTY PRODUCTS AND SERVICES REFERENCED HEREIN INCLUDING WITHOUT LIMITATION ANY OF THE FOLLOWING DAMAGES: DIRECT, CONSEQUENTIAL, EXEMPLARY, INCIDENTAL, INDIRECT, SPECIAL, PUNITIVE, OR AGGRAVATED DAMAGES, DAMAGES FOR LOSS OF PROFITS OR REVENUES, FAILURE TO REALIZE ANY EXPECTED SAVINGS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, LOSS OF BUSINESS OPPORTUNITY, OR CORRUPTION OR LOSS OF DATA, FAILURES TO TRANSMIT OR RECEIVE ANY DATA, PROBLEMS ASSOCIATED WITH ANY APPLICATIONS USED IN CONJUNCTION WITH RIM PRODUCTS OR SERVICES, DOWNTIME COSTS, LOSS OF THE USE OF RIM PRODUCTS OR SERVICES OR ANY PORTION THEREOF OR OF ANY AIRTIME SERVICES, COST OF SUBSTITUTE GOODS, COSTS OF COVER, FACILITIES OR SERVICES, COST OF CAPITAL, OR OTHER SIMILAR PECUNIARY LOSSES, WHETHER OR NOT SUCH DAMAGES WERE FORESEEN OR UNFORESEEN, AND EVEN IF RIM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW IN YOUR JURISDICTION, RIM SHALL HAVE NO OTHER OBLIGATION, DUTY, OR LIABILITY WHATSOEVER IN CONTRACT, TORT, OR OTHERWISE TO YOU INCLUDING ANY LIABILITY FOR NEGLIGENCE OR STRICT LIABILITY.

THE LIMITATIONS, EXCLUSIONS, AND DISCLAIMERS HEREIN SHALL APPLY: (A) IRRESPECTIVE OF THE NATURE OF THE CAUSE OF ACTION, DEMAND, OR ACTION BY YOU INCLUDING BUT NOT LIMITED TO BREACH OF CONTRACT, NEGLIGENCE, TORT, STRICT LIABILITY OR ANY OTHER LEGAL THEORY AND SHALL SURVIVE A FUNDAMENTAL BREACH OR BREACHES OR THE FAILURE OF THE ESSENTIAL PURPOSE OF THIS AGREEMENT OR OF ANY REMEDY CONTAINED HEREIN; AND (B) TO RIM AND ITS AFFILIATED COMPANIES, THEIR SUCCESSORS, ASSIGNS, AGENTS, SUPPLIERS (INCLUDING AIRTIME SERVICE PROVIDERS), AUTHORIZED RIM DISTRIBUTORS (ALSO INCLUDING AIRTIME SERVICE PROVIDERS) AND THEIR RESPECTIVE DIRECTORS, EMPLOYEES, AND INDEPENDENT CONTRACTORS.

IN ADDITION TO THE LIMITATIONS AND EXCLUSIONS SET OUT ABOVE, IN NO EVENT SHALL ANY DIRECTOR, EMPLOYEE, AGENT, DISTRIBUTOR, SUPPLIER, INDEPENDENT CONTRACTOR OF RIM OR ANY AFFILIATES OF RIM HAVE ANY LIABILITY ARISING FROM OR RELATED TO THE DOCUMENTATION.

Prior to subscribing for, installing, or using any Third Party Products and Services, it is your responsibility to ensure that your airtime service provider has agreed to support all of their features. Some airtime service providers might not offer Internet browsing functionality with a subscription to the BlackBerry® Internet Service. Check with your service provider for availability, roaming arrangements, service plans and features. Installation or use of Third Party Products and Services with RIM's products and services may require one or more patent, trademark, copyright, or other licenses in order to avoid infringement or violation of third party rights. You are solely responsible for determining whether to use Third Party Products and Services and if any third party licenses are required to do so. If required you are responsible for acquiring them. You should not install or use Third Party Products and Services until all necessary licenses have been acquired. Any Third Party Products and Services that are provided with RIM's products and services are provided as a convenience to you and are provided "AS IS" with no express or implied conditions, endorsements, guarantees, representations, or warranties of any kind by RIM and RIM assumes no liability whatsoever, in relation thereto. Your use of Third Party Products and Services shall be governed by and subject to you agreeing to the terms of separate licenses and other agreements applicable thereto with third parties, except to the extent expressly covered by a license or other agreement with RIM.

Certain features outlined in this documentation require a minimum version of BlackBerry® Enterprise Server, BlackBerry® Desktop Software, and/or BlackBerry® Device Software.

The terms of use of any RIM product or service are set out in a separate license or other agreement with RIM applicable thereto. NOTHING IN THIS DOCUMENTATION IS INTENDED TO SUPERSEDE ANY EXPRESS WRITTEN AGREEMENTS OR WARRANTIES PROVIDED BY RIM FOR PORTIONS OF ANY RIM PRODUCT OR SERVICE OTHER THAN THIS DOCUMENTATION.

PCRE is a library of functions to support regular expressions whose syntax and semantics are as close as possible to those of the Perl 5 language.

This is JavaScriptCore's variant of the PCRE library. While this library started out as a copy of PCRE, many of the features of PCRE have been removed.

Copyright (c) 1997-2005 University of Cambridge. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the University of Cambridge nor the name of Apple Inc. nor the names of their contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Research In Motion Limited
295 Phillip Street
Waterloo, ON N2L 3W8
Canada

Research In Motion UK Limited
Centrum House
36 Station Road
Egham, Surrey TW20 9LF
United Kingdom

Published in Canada